

## Configurable parameters for the Polaris RZR Drive-By-Wire Kit

---

### 1 Overview

The parameters described in this document allow configuration of several features of the drive-by-wire system. Parameters can be changed using the DbwConfig.exe Windows application and connecting to modules via USB. See DbwConfig.pdf for details on this process.

Parameters are stored in non-volatile memory, so it is not necessary to set the values each power cycle. The section of non-volatile is not erased by the firmware upgrade process, so values persist between firmware upgrades. If the min/max range changes for a parameter, the value will be sanitized to the new min/max range. It is recommended to visually check the parameter values after a firmware upgrade.

Parameter changes are active immediately, however, it is unwise to change parameters when the vehicle is in motion. Exercise caution when using non-default parameter values, as this will change the way the drive-by-wire system operates.

### DISCLAIMER:

This product is intended for research purposes only. Steps have been taken to ensure function on power or communication loss. However, in no event shall Dataspeed Inc. be liable for any direct, indirect, punitive, incidental, special consequential damages, to property or life, whatsoever arising out of or connected with the use or misuse of its products.

---

## 2 Throttle Module

### 2.1 Allow Ignoring Driver Overrides

| Name        | Default | Min | Max | Unit |
|-------------|---------|-----|-----|------|
| AllowIgnore | False   | —   | —   | —    |

This parameter enables or disables the ability of the user to ignore driver overrides by setting the IGNORE bit in the throttle command message (ID 0x062). Use extra caution when allowing the drive-by-wire to ignore driver overrides. Drive-by-wire and driver input is always merged, but ignoring overrides will prevent the driver from taking back complete control.

### 2.2 Driver Override Threshold

| Name           | Default | Min  | Max  | Unit |
|----------------|---------|------|------|------|
| OverrideThresh | 0.30    | 0.15 | 0.70 | %    |

The override threshold parameter controls how far the user must press the throttle pedal to trigger a driver override. The value of this parameter represents the raw pedal position.

### 2.3 Driver Override Hysteresis Time

| Name           | Default | Min | Max | Unit |
|----------------|---------|-----|-----|------|
| OverrideHystMs | 100     | 0   | 250 | ms   |

The driver override hysteresis time parameter controls how many consecutive milliseconds the override threshold must be exceeded before a driver override is triggered.

### 2.4 Suppress Watchdog Counter Faults

| Name                | Default | Min | Max | Unit |
|---------------------|---------|-----|-----|------|
| WdcSuppressDisabled | False   | —   | —   | —    |

If set, the three fault sources for the Watchdog Counter in the table below are not considered. This allows commands to transition from EN=1 to EN=0 without triggering a Watchdog Counter fault. All modules independently determine these fault conditions, so this value should be the same for all modules in the same vehicle.

| Value | Enum              | Description  |
|-------|-------------------|--|
| 5     | BRAKE_DISABLED    | Brake module disabled without override when in gear or moving    |
| 9     | THROTTLE_DISABLED | Throttle module disabled without override when in gear or moving |
| 13    | STEERING_DISABLED | Steering module disabled without override when in gear or moving |

---

## 3 Gateway Module

### 3.1 Steer Allow Ignoring Driver Overrides

| Name             | Default | Min | Max | Unit |
|------------------|---------|-----|-----|------|
| SteerAllowIgnore | False   | —   | —   | —    |

This parameter enables or disables the ability of the user to ignore driver overrides by setting the IGNORE bit in the steering command message (ID 0x064). Use extra caution when allowing the drive-by-wire to ignore driver overrides. Drive-by-wire and driver input is always merged, but ignoring overrides will prevent the driver from taking back complete control.

### 3.2 Steering Driver Override Threshold

| Name                | Default | Min  | Max   | Unit |
|---------------------|---------|------|-------|------|
| SteerOverrideThresh | 8.00    | 4.00 | 10.00 | Nm   |

The override threshold parameter controls how much torque the user must induce on the steering column to trigger a driver override.

### 3.3 Steering Acceleration Limit

| Name               | Default | Min | Max   | Unit               |
|--------------------|---------|-----|-------|--------------------|
| SteeringAccelLimit | 3600    | 0   | 10000 | deg/s <sup>2</sup> |

Limit the amount of angular acceleration on the steering wheel angle command. Zero evaluates to no-limit.

### 3.4 Unlimited Steering Velocity

| Name              | Default | Min | Max | Unit |
|-------------------|---------|-----|-----|------|
| UnlimitedSteering | False   | —   | —   | —    |

If false, SVEL=0 corresponds to a 500 deg/s steering velocity limit. If true, SVEL=0 corresponds to unlimited steering velocity and the steering acceleration limit above is ignored. Use caution with unlimited steering velocity. Sporadic and jerky steering commands may cause unintended driver overrides that will transition control back to the human driver.

### 3.5 Steering Calibration Status

| Name        | Default | Min | Max | Unit |
|-------------|---------|-----|-----|------|
| SteeringCal | False   | —   | —   | —    |

If false, steering has not been calibrated. If true, SteeringCalOffset is the steering calibration. This parameter is set automatically.

### 3.6 Steering Calibration Offset

| Name              | Default | Min    | Max   | Unit |
|-------------------|---------|--------|-------|------|
| SteeringCalOffset | 0       | -10000 | 10000 | deg  |

The calibrated offset between steering wheel angle and steering motor angle. Only valid if SteeringCal is true. This parameter is set automatically.

### 3.7 Lateral Acceleration Limit

| Name          | Default | Min | Max  | Unit             |
|---------------|---------|-----|------|------------------|
| LatAccelLimit | 7.0     | 2.0 | 18.0 | m/s <sup>2</sup> |

This parameter is used to limit the amount of lateral acceleration that can be achieved when commanding steering wheel angle. It does this by limiting the maximum allowed steering wheel angle according to the following relationship:

$$\alpha_{s_{\max}} = \gamma \tan^{-1} \left( \frac{L a_{y_{\max}}}{v^2} \right)$$

where  $\alpha_{s_{\max}}$  is the maximum steering wheel angle in radians,  $\gamma = 13$  is the ratio between the steering wheel angle and the tire steering angle,  $L = 2.286$  is the length of the wheelbase in meters,  $v$  is the current speed of the vehicle in m/s, and  $a_{y_{\max}}$  is the lateral acceleration limit specified in this parameter.

The maximum value effectively disables this safety feature. For typical driving situations, appropriate values for this parameter range between 4 m/s<sup>2</sup> and 8 m/s<sup>2</sup>.

### 3.8 Angular Acceleration Limit

| Name          | Default | Min | Max  | Unit               |
|---------------|---------|-----|------|--------------------|
| AngAccelLimit | 4.0     | 0.5 | 10.0 | rad/s <sup>2</sup> |

This parameter is used to limit the amount of vehicle angular acceleration that can be achieved when commanding steering wheel angular rate. It does this by limiting the maximum allowed angular rate of the steering wheel according to the following relationship:

$$\dot{\alpha}_{s_{\max}} = \frac{\gamma L}{v} \cos^2 \left( \frac{\alpha_s}{\gamma} \right) \ddot{\psi}_{\max}$$

where  $\dot{\alpha}_{s_{\max}}$  is the maximum steering wheel rate in rad/s,  $\gamma = 13$  is the ratio between the steering wheel angle and the tire steering angle,  $L = 2.286$  is the length of the wheelbase in meters,  $v$  is the current speed of the vehicle in m/s,  $\alpha_s$  is the current steering wheel angle, and  $\ddot{\psi}_{\max}$  is the angular acceleration limit specified in this parameter.

The maximum value effectively disables this safety feature. For typical driving situations, appropriate values for this parameter range between 2 rad/s<sup>2</sup> and 4 rad/s<sup>2</sup>.

### 3.9 Brake Allow Ignoring Driver Overrides

| Name             | Default | Min | Max | Unit |
|------------------|---------|-----|-----|------|
| BrakeAllowIgnore | False   | —   | —   | —    |

This parameter enables or disables the ability of the user to ignore driver overrides by setting the IGNORE bit in the brake command message (ID 0x060). Use extra caution when allowing the drive-by-wire to ignore driver overrides. Drive-by-wire and driver input is always merged, but ignoring overrides will prevent the driver from taking back complete control.

### 3.10 Brake Driver Override Threshold

| Name                | Default | Min | Max  | Unit |
|---------------------|---------|-----|------|------|
| BrakeOverrideThresh | 1000    | 50  | 2500 | Nm   |

The override threshold parameter controls how far the user must press the brake pedal to trigger a driver override. The value of this parameter represents the torque induced by pressing the brake pedal.

---

### 3.11 Brake Driver Override Hysteresis Time

| Name                | Default | Min | Max | Unit |
|---------------------|---------|-----|-----|------|
| BrakeOverrideHystMs | 250     | 50  | 500 | ms   |

The driver override hysteresis time parameter controls how many consecutive milliseconds the override threshold must be exceeded before a driver override is triggered.

### 3.12 External Brake Input Enable

| Name           | Default | Min | Max | Unit |
|----------------|---------|-----|-----|------|
| ExtBrakeEnable | False   | —   | —   | —    |

If enabled, a low voltage on digital input 2 will trigger a constant braking value. The external brake input is the highest priority braking command source, and will trigger regardless of the the brake command CAN message and the state of the Watchdog Counter fault. This input is useful as an emergency stop button. The default is a 'large' amount of braking.

### 3.13 External Brake Input Value

| Name          | Default | Min | Max  | Unit |
|---------------|---------|-----|------|------|
| ExtBrakeValue | 3000    | 0   | 8000 | Nm   |

This is the value for the constant braking of the external brake input described above.

### 3.14 Watchdog Counter Brake Value

| Name          | Default | Min | Max  | Unit |
|---------------|---------|-----|------|------|
| WdcBrakeValue | 1000    | 0   | 5000 | Nm   |

This is the value for the constant braking when the Watchdog Counter fault is triggered. The default is a 'small' amount of braking, just enough to slowly bring the vehicle to a stop.

### 3.15 Suppress Watchdog Counter Faults

| Name                | Default | Min | Max | Unit |
|---------------------|---------|-----|-----|------|
| WdcSuppressDisabled | False   | —   | —   | —    |

If set, the three fault sources for the Watchdog Counter in the table below are not considered. This allows commands to transition from EN=1 to EN=0 without triggering a Watchdog Counter fault. All modules independently determine these fault conditions, so this value should be the same for all modules in the same vehicle.

| Value | Enum              | Description  |
|-------|-------------------|--|
| 5     | BRAKE_DISABLED    | Brake module disabled without override when in gear or moving    |
| 9     | THROTTLE_DISABLED | Throttle module disabled without override when in gear or moving |
| 13    | STEERING_DISABLED | Steering module disabled without override when in gear or moving |

### 3.16 Brake Calibration Clear

| Name          | Default | Min | Max | Unit |
|---------------|---------|-----|-----|------|
| BrakeCalClear | False   | —   | —   | —    |

Clear the brake calibration table and trigger the calibration procedure. The value resets to False automatically.

### 3.17 Shift Calibration Clear

| Name          | Default | Min | Max | Unit |
|---------------|---------|-----|-----|------|
| ShiftCalClear | False   | —   | —   | —    |

Clear the shift calibration table and trigger the calibration procedure. The value resets to False automatically.

### 3.18 UlcStopTorque

| Name          | Default | Min | Max  | Unit |
|---------------|---------|-----|------|------|
| UlcStopTorque | 800     | 600 | 1600 | Nm   |

This parameter specifies the constant amount of brake torque used to maintain zero speed.

### 3.19 UlcDefaultLatAccel

| Name               | Default | Min | Max | Unit             |
|--------------------|---------|-----|-----|------------------|
| UlcDefaultLatAccel | 4.0     | 2.0 | 6.0 | m/s <sup>2</sup> |

When the ULC configuration message is in timeout, or its LAT\_ACCEL field is set to zero, this parameter is used to limit the amount of lateral acceleration that can be achieved with the steering component of the ULC. It does this by limiting the maximum allowed steering wheel angle according to the following relationship:

$$\alpha_{s_{\max}} = \gamma \tan^{-1} \left( \frac{L a_{y_{\max}}}{v^2} \right)$$

where  $\alpha_{s_{\max}}$  is the maximum steering wheel angle in radians,  $\gamma = 13$  is the ratio between the steering wheel angle and the tire steering angle,  $L = 2.286$  is the length of the wheelbase in meters,  $v$  is the current speed of the vehicle in m/s, and  $a_{y_{\max}}$  is the lateral acceleration limit specified in this parameter.

### 3.20 UlcDefaultAngAccel

| Name               | Default | Min | Max | Unit               |
|--------------------|---------|-----|-----|--------------------|
| UlcDefaultAngAccel | 1.0     | 0.5 | 2.0 | rad/s <sup>2</sup> |

When the ULC configuration message is in timeout, or its ANG\_ACCEL field is set to zero, this parameter is used to limit the amount of angular acceleration that can be achieved with the steering component of the ULC. It does this by limiting the maximum allowed angular rate of the steering wheel according to the following relationship:

$$\dot{\alpha}_{s_{\max}} = \frac{\gamma L}{v} \cos^2 \left( \frac{\alpha_s}{\gamma} \right) \ddot{\psi}_{\max}$$

where  $\dot{\alpha}_{s_{\max}}$  is the maximum steering wheel rate in rad/s,  $\gamma = 13$  is the ratio between the steering wheel angle and the tire steering angle,  $L = 2.286$  is the length of the wheelbase in meters,  $v$  is the current speed of the vehicle in m/s,  $\alpha_s$  is the current steering wheel angle, and  $\ddot{\psi}_{\max}$  is the angular acceleration limit specified in this parameter.

---

### 3.21 UlcDefaultLinDecel

| Name               | Default | Min | Max | Unit             |
|--------------------|---------|-----|-----|------------------|
| UlcDefaultLinDecel | 1.5     | 0.5 | 3.0 | m/s <sup>2</sup> |

When the ULC configuration message is in timeout, or its LIN\_DECEL field is set to zero, this parameter is used to limit the amount of deceleration used to regulate vehicle speed.

### 3.22 Wireless Remote Throttle Percent

| Name                  | Default | Min  | Max  | Unit |
|-----------------------|---------|------|------|------|
| RemoteThrottlePercent | 0.50    | 0.00 | 1.00 | %    |

This value defines the maximum throttle value and scale factor for the throttle joystick axis on wireless remote control.

### 3.23 Wireless Remote Brake Percent

| Name               | Default | Min  | Max  | Unit |
|--------------------|---------|------|------|------|
| RemoteBrakePercent | 0.50    | 0.00 | 1.00 | %    |

This value defines the maximum brake value and scale factor for the brake joystick axis on wireless remote control.

### 3.24 Wireless Remote Steering Angle

| Name                | Default | Min | Max   | Unit |
|---------------------|---------|-----|-------|------|
| RemoteSteeringAngle | 360.0   | 0.0 | 440.0 | deg  |

This value defines the maximum steering wheel angle value and scale factor for the steering joystick axis on wireless remote control.

---

## Appendix – Steering Angle and Rate Limit Derivations

This appendix documents the mathematical derivation of the speed-dependent limits on steering wheel angle and steering wheel rate based on the LatAccelLimit calibration parameter (Section 3.7) and the AngAccelLimit calibration parameter (Section 3.8), respectively. These derivations are based on a kinematic bicycle model, illustrated in Figure 1.




Figure 1: Diagram of a kinematic bicycle model

where  $\alpha$  is the equivalent bicycle steering angle of the front wheels,  $R$  is the turning radius,  $L = 2.286\text{m}$  is the wheelbase of the vehicle, and the vehicle's coordinate frame is defined with  $x$  pointing forward,  $y$  pointing left, and  $z$  pointing up.

### Speed-Dependent Angle Limit

The speed-dependent maximum allowed steering wheel angle is computed based on a user-specified maximum allowed lateral acceleration set in the LatAccelLimit calibration parameter. Lateral acceleration is linked to speed and turning radius through the formula for centripetal acceleration:

$$a_y = \frac{v^2}{R} \quad (1)$$

Representing turning radius in terms of the steering angle  $\alpha$  and substituting into (1) gives:

$$a_y = \frac{v^2 \tan \alpha}{L} \quad (2)$$

Defining the ratio between steering wheel angle and the equivalent bicycle steering angle of the front wheels as the steering ratio, and representing that ratio as  $\gamma = 13.0$ , (2) can be manipulated to express lateral acceleration in terms of the steering wheel angle:

$$a_y = \frac{v^2 \tan \left( \frac{\alpha_s}{\gamma} \right)}{L} \quad (3)$$



where  $\alpha_s$  is the steering wheel angle. Rearranging to represent the maximum steering wheel angle in terms of a lateral acceleration limit setting:

$$\alpha_s = \gamma \tan^{-1} \left( \frac{La_y}{v^2} \right) \quad (4)$$

### Speed-Dependent Angle Rate Limit

The speed-dependent maximum allowed steering wheel rate is computed based on a user-specified maximum allowed angular acceleration set in the AngAccelLimit calibration parameter. Angular acceleration is defined as the time derivative of yaw rate, so an expression for the yaw rate in terms of the kinematics parameters and steering wheel angle is required first. This can be constructed using the formula (5) relating arc length, angle, and radius, illustrated in Figure 2.

$$s = R\theta \quad (5)$$




Figure 2: Arc length, angle, and radius

Taking the time derivative of both sides of (5):

$$\frac{ds}{dt} = R \frac{d\theta}{dt} \quad (6)$$

where  $ds/dt \equiv v$  is the forward speed of the vehicle, and  $d\theta/dt \equiv \dot{\psi}$  is the yaw rate. Substituting into (6) the same expression as before for the vehicle's turning radius, the yaw rate can be expressed in terms of the steering wheel angle:

$$\dot{\psi} = \frac{v \tan \left( \frac{\alpha_s}{\gamma} \right)}{L} \quad (7)$$

Taking the time derivative of (7) gives an expression of the angular acceleration:

$$\frac{d\dot{\psi}}{dt} = \frac{1}{L} \left( \frac{dv}{dt} \tan \left( \frac{\alpha_s}{\gamma} \right) + v \frac{d \left( \tan \left( \frac{\alpha_s}{\gamma} \right) \right)}{dt} \right) = \frac{v \dot{\alpha}_s}{L \gamma} \sec^2 \left( \frac{\alpha_s}{\gamma} \right) \quad (8)$$

where  $d\dot{\psi}/dt \equiv \ddot{\psi}$  is the angular acceleration,  $\dot{\alpha}_s$  is the steering wheel rate, and it is assumed the vehicle's speed is in steady state with acceleration ( $dv/dt$ ) equal to zero. Rearranging to represent the maximum steering wheel angle rate in terms of an angular acceleration limit setting:

$$\dot{\alpha}_s = \frac{L \gamma}{v} \cos^2 \left( \frac{\alpha_s}{\gamma} \right) \ddot{\psi} \quad (9)$$